


Finding your way around POWERMAX

Most of the programming of Powermax is performed using the six keys located on the front of the control panel. Take just a few moments to understand your way around the keyboard. Menus are selected using **NAVIGATION KEYS** (see diagram) to go through the options. When you see the option you require simply press [OK], this will take you into the sub menu where the same principle is used. When you find the option you require press [OK]. To change the selected options NAVIGATE until you see the setting you require and press [OK] twice (you will hear the confirmation tone)



If at any stage you wish to
Go back a level in programming
Press [HOME] to go back, each further
Press of [HOME] will take you further
back

The off key is used as a delete key and would for example be used to delete an enrolled device by selecting it's zone number in 'enrolment' and pressing [OFF] when prompted to do so

ENTERING ENGINEER MODE:
Press NEXT until **INSTALLER** is displayed Press OK and key in 9999